www.morphyrichards.com

MODEL 21035

Diamond IONIC DRYER

for volume & shine

INSTRUCTIONS & GUARANTEE

morphy richards

HOW DOES DIAMOND IONIC TECHNOLOGY WORK?

Diamond the most hard wearing & durable material is applied to the grille. Ionic is a technology which emits negative ions to reduce frizz & static of the hair whilst drying. NEW Diamond application enhances the ionic technology to improve the performance of the dryer therefore creating beautiful shiny hair.

For electrical products sold within the European Community. At the end of the electrical products useful life it should not be disposed of with household waste.
Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

2-YEAR GUARANTEE

It is in your interest to retain the retailers receipt as proof of purchase. Please quote the model number if the product develops a fault. This number can be found on the handle of the product.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase it should be returned to the place of purchase for it to be replaced.

If a fault develops after 28 days and within 24 months of original purchase, you should contact the helpline number quoting the model number of the product, or write to the address below.
You will be asked to return the product (in secure packaging) to the address below along with a copy of proof of purchase:

The After Sales Division
Morphy Richards Ltd
Mexborough
South Yorkshire
England
S64 8AJ

www.morphyrichards.com

HELPLINE

(8.30-5.00 Monday-Thursday/8.30-4.00 Friday)
UK 0870 060 2614
Republic of Ireland 1800 409119

Morphy Richards's products are intended for household use only. Morphy Richards has a policy of continuous improvement in product quality and design. The company therefore reserves the right to change the specification of its models at any time.

Part Number – PC21035 MUK REV 1
Model number - 21035

CE

Registered address:
Morphy Richards Ltd
Mexborough
South Yorkshire S64 8AJ
www.morphyrichards.com

USING YOUR HAIR DRYER:

① Having shampooed your hair, ensure that it is rinsed thoroughly as shampoo that is left in the hair will leave it looking dull.

② Comb your hair through with a wide-tooth comb to remove tangles before styling.

③ Ensure the concentrator nozzle & diffuser (diffuser only with 21036) attachment are detached.

④ Move the on/off switch to position to turn the hair dryer on.

⑤ Use the three heat and two speed settings to make the dryer operate faster and hotter, to help remove excess water from your hair.

⑥ As your hair begins to dry, switch off the hair dryer and clip on the concentrator nozzle or diffuser (diffuser only with 21036) to begin styling your hair. For a straight style, use the concentrator to direct air down into the shaft of hair.

Straight

⑦ As you begin to style your hair during drying, move the heat and speed buttons to select a slower and cooler setting use cool shot to set the style.

Curly

⑧ If you want to create volume instead, attach the diffuser (only with 21036) to your hair dryer. Switch off the hair dryer then push the diffuser onto the end of the hair dryer ensuring it clicks into place. Collecting hair in the diffuser as you dry will give you a textured/tousled look or will enhance natural curls.

⑨ When your hair is dry, and you have achieved the desired style, press the cool shot button . This will release a burst of cold air which will set your style in place. Press the button again to return to normal styling temperature.

⑩ Always remember to switch the on/off button to the position **0**, to turn your hair dryer off.

ALWAYS CLEAN YOUR FILTER

Cleaning the air filter regularly will ensure that only clean air is used to dry your hair and that the dryer will not overheat and cut out. To remove the air filter, enure the hair dryer is unplugged from the mains supply. Hold the body of the dryer firmly while pressing in the two sides of the filter and pulling it to release. Clean away hair and lint from the filter. Ensure the filter is completely dry before refitting. To re-fit, align the filter on the dryer and push back into place.

WIRING

The product is fitted with a 13A (BS1363) plug. A 13A fuse (BS1362) must be used. Check the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be AC (Alternating Current). If the socket outlets in your home are not suitable for the plug supplied with this appliance the plug should be removed and an appropriate one fitted.

IMPORTANT: THE PLUG, REMOVED FROM THE MAINS LEAD, IF SEVERED, MUST BE DESTROYED AS A PLUG WITH BARED FLEXIBLE CORD IS HAZARDOUS IF ENGAGED INTO A LIVE SOCKET OUTLET.

MAINS LEAD

As a safety precaution, and to prolong the life of your appliance, do not wrap the mains lead around the appliance as this can cause damage.

SAFETY INFORMATION

When using your hair dryer, basic safety precautions should always be followed. Please read these instructions carefully before using the product, and keep them in a safe place for future reference.

① Use this appliance for its intended use only.

② To protect against the risk of electric shock, do not immerse the appliance in water or in any other liquids.

③ Check the voltage on the rating plate of the hair dryer corresponds with your house electricity supply which must be AC (Alternating Current).

④ Always unplug the appliance when it is not in use.

⑤ Do not leave the hairdryer switched on whilst unattended.

⑥ WARNING (for UK only): Do not use this appliance near bathrooms, showers, basins or other vessels containing water.

WARNING: (for other European countries) For additional protection, the installation of a residual current device (RCD) having rated residual operating current not exceeding 30mA is advised in the electrical circuit supplying the bathroom. Ask your installer for advice.

⑦ In the event of supply cord/cable damage, do not attempt to replace mains cable. It should be returned to Morphy Richards in order too avoid a hazard. When the hair dryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hair dryer is switched off.

⑧ This appliance is not intended for use by children or other persons without assistance or supervision, if their physical, sensory or mental capabilities prevent them from using it safely. Keep out of reach of children at all times.

⑨ Do not place on surfaces that are likely to be damaged by heat.

⑩ Ensure the filter is cleaned regularly.

PRODUCT FEATURES:

Stylish & Ergonomically designed
unique to Morphy Richards ensuring ease of use.
Removable air filter
for easy cleaning to maintain the dryer performance
2000w
ensuring the power but a lightweight balanced design.
3 heat, 2 speed & Cool shot setting
for versatile settings for all hair types and styles.
3M salon cable & hanging loop
for flexible use & convenient storage
Dimond Ionic feature
to protect and enrich, reduce the elasticity and smooth the hair to the tip, producing quicker and kinder drying to your hair.
Slim concentrator nozzle
for controlled and easy styling
Deep bowl diffuser
to creating the ultimate curly styled finish, perfect for long hair. (Only with 21036)